

INSIDE CORNER INSTALLATIONS

- Surface mounting on the indoor side of the wall on an inside corner usually results in huge gaps on the sides with the shades made narrower to avoid conflicting with each other.
- Undermount inside the openings, or surface mount on the outdoor side if possible.
- If not possible, and your indoor wall/beam space is at least
 - 11 ½" for Grande (14 ½" if you don't want the bottom bar of the lower shades to show in the opening)
 - 10 ½" for Baby Grande (13 ½" if you don't want the bottom bar of the lower shades to show in the opening)

You can do a 'High/Low' installation

- Decide which area needs the most coverage. That shade will be ordered at opening width minus ½" for fit and will be the High shade.
- The other shade will be the Low shade and be ordered 2 ¾" narrower than the space to allow the bottom bar and fabric of the High shade to drop down behind the end caps of the Under shade.

